

## ***Installation Instructions: Bottom Load Pleated Bags (Style FM & MM)***

### ***FILTER INSTALLATION***

- 1. Grip the filter at the top and slide molded filter boot up onto the tube sheet cup until the retaining bead engages the groove in the tube sheet cup.*
- 2. Fasten a band clamp around the upper groove of the molded filter boot and secure.*
- 3. Check installation for straightness.*

### ***FILTER REMOVAL***

- 1. To remove the filter, loosen and remove the band clamp.*
- 2. Gripping the filter at the top end, gently work the filter off of the tube sheet cup.*

