



## ***Filter Cleaning: Spun Bond Polyester Cartridges***

*ECOSPUN polyester filter cartridges can be cleaned, however, you must follow the instructions below and use caution.*

### ***DO NOT USE:***

*High-pressure air or water*

*Brushes*

*Oils, solvents, or harsh detergents*

*Wash filter from the dirty side of the filter*

### ***INSTRUCTIONS:***

*Pulse the filter off line prior to removing the filter from the collector.*

*Remove the filter from the collector.*

*Blow the contaminant off the filter with the cleanest (non-wet) air available.*

*Wash the filter with a low pressure washer from the **INSIDE** of the cartridge.*

*Use 40 – 45 PSIG.*

*Let the filters dry for 72 hours (or install in collector and run fan only until dry).*

***FILTERS MUST BE THOROUGHLY DRY BEFORE RUNNING IN NORMAL OPERATION***